

HOW TO PROGRAM THE INTELLIGENT CONTROL

LEGEND

Button and up or down arrows will be referenced and look here to see what button or what arrow is referenced to.



HOW TO PROGRAM CONTROLLER FOR 1 DAY A WEEK

- 1) When the temperature is in the middle of the screen (like the photo above).
- 2) Press the RIGHT-HAND BUTTON once.
- 3) Press the DOWN ARROW until "PROGRAM" is highlighted.
- 4) Press the RIGHT-HAND BUTTON once.
- 5) Press the DOWN ARROW once.
- 6) "PROGRAM TYPE" will be at the top of the screen and "Standard" will be in the middle of the screen. Press the RIGHT BUTTON once and "Standard" will become highlighted.

- 7) Press the DOWN ARROW once and "Custom" will be in the middle of the screen and push the RIGHT-HAND BUTTON once and then press the UP ARROW once.
- 8) Now press the RIGHT-HAND BUTTON once and "Weekday" will be at the top of the screen.
- 9) When "Sunday" is highlighted press the RIGHT-HAND BUTTON once
- 10) Press the DOWN ARROW until "Set" is highlighted and press the RIGHT-HAND BUTTON once.
- 11) 1 Period basically means it turn ON and OFF 1 time and 2 Periods turns on and off TWICE choose which one you would like and highlight the one you want and then press the RIGHT-HAND BUTTON once.
- 12) "P1: Start time" will appear at the top of the screen and the Hour will be highlighted first press the UP ARROW or DOWN ARROW until you get to the desired hour of when the underfloor heating is to turn on and press the RIGHT-HAND BUTTON to confirm
- 13) The minutes will now be highlighted again repeat the same as done in part 12 and chose the selected minute and press the RIGHT-HAND BUTTON once to confirm.
- 14) "P1: END TIME" repeat the process in part 12 and 13.
- 15) "Temperature" will be at the top of the screen and "Comfort:23.0°C" will be in the middle of the screen press the UP ARROW or DOWN ARROW until it gets to the desired temperature and once you get to the wanted temperature and press the RIGHT-HAND BUTTON once to confirm
- 16) If "2 Periods" was selected repeat steps 12 – 15 and where "P1" Stated it will instead say "P2".
- 17) This is how you can program each day of the week repeat steps 9 – 16 for each week day

HOW TO COPY AND SET EVERY DAY TO BE THE SAME TIME AND TEMPERATURE

- 1) If you want Sunday – Saturday to be the exact time and temperature that it turns on at then do the following.

- 2) When "Sunday" has been programmed , you should be in the part where "Weekday" is at the top of the screen , press the RIGHT-HAND BUTTON once when "Sunday" is highlighted
- 3) Press the DOWN ARROW until "Copy" is highlighted and then press the RIGHT-HAND BUTTON once.
- 4) It will take you back to the "Weekday" press the DOWN ARROW until "Monday" is selected or the day you want the program copied to and then press the RIGHT-HAND BUTTON once.
- 5) Then when the day is at the top (the day you have selected that you want to copy the program to) press the DOWN ARROW until "Paste" is highlighted and then press the RIGHT-HAND BUTTON once it will say "PASTED OK!"
- 6) Press the DOWN ARROW until "Back" is highlighted and press the RIGHT-HAND BUTTON once and "Weekday" will appear at the top of the screen.
- 7) Repeat steps 2 -6 for copying all the programs to all the other week days